



# TOLI Product Maintenance

*FasolPlus / Lightstone / Lightwood / Linotesta / Mature / Viale*

## Safety Precautions

- When performing any wet maintenance, always use wet floor signs and caution tape.
- Refer to each product's MSDS for use of personal protective equipment.



## Newly Installed Floor Care

- Keep all foot traffic off the new floor for 12 hours.
- Keep furniture, fixtures and rolling traffic off the new floor for 48 hours.
- Use plywood or other boards when moving heavy objects across the floor.
- Remove adhesive residue with a clean white cloth dampened with mineral spirits. Do not use AFTA.
- Lightly damp mop the floor as needed.
- Wait 72 hours before wet washing and scrubbing the new floor. This will allow the adhesive to fully cure.

## Initial Maintenance

- Sweep or dust mop to remove dirt and grit. Do not use treated dust mops.
- Add heavy duty cleaner to cool water following the manufacturer's instructions.
- Scrub with a 175-rpm machine or auto scrubber. Use a **blue or green pad**. Always wet the pad before use. **Never use a black or a build-up removal pad.**
- Remove the solution with a wet-dry vacuum or auto scrubber until the floor is dry and free of residue.
- Rinse the floor with clean water. Repeat the rinse process as necessary to remove all haze and residue.
- Apply three to five coats of high gloss or matte floor finish following the manufacturer's instructions.

## Routine Maintenance

- Sweep or dust mop to remove dirt and grit. Do not use treated dust mops.
- Add neutral pH cleaner to cool water following the manufacturer's instructions.
- Rinse the mop in clean water after each mopping pass to remove picked up soil.
- Periodically, scrub with a 175-rpm machine or auto scrubber to retain appearance. Use a **red pad** and heavy duty cleaner following the manufacturer's instructions.

## Periodic Deep Cleaning

- Sweep or dust mop the floor to remove dirt and grit. Do not use treated dust mops.
- Add heavy duty cleaner to cool water following the manufacturer's instructions.
- Scrub with a 175-rpm machine or auto scrubber. Use a **green pad**. Always wet the pad before use. **Never use a black or a build-up removal pad.**
- Remove the solution with a wet-dry vacuum or auto scrubber until the floor is dry and free of residue.
- Rinse the floor with clean water. Repeat the rinse process as necessary to remove all haze and residue.
- Apply two coats of high gloss or matte floor finish following the manufacturer's instructions.

## Stripping Procedure

- Sweep or dust mop the floor to remove dirt and grit. Do not use treated dust mops.
- Add stripper to cool water following the manufacturer's instructions.
- Scrub with a 175-rpm machine or auto scrubber. Use a **green or blue pad**. Always wet the pad before use. **Never use a black or a build-up removal pad.**
- Apply three coats of high gloss or matte floor finish following the manufacturer's instructions.

## Preventative Floor Care

- Proper matting system is recommended. Mats should be appropriate for soil load and weather conditions. Use mats with a non-staining backing.
- Floor protectors should be used on all furniture legs. The surface area of the floor glide should be no less than 1" in diameter.
- Protect the floor from direct sunlight.

## Recommended Maintenance Products

- For a list of recommended maintenance products, please refer to our [Maintenance Product Guide](#) for TOLI Flooring.

## Contact Information

For additional information, please call 1-800-446-5476  
Email: [support@toli.com](mailto:support@toli.com)  
[www.toli.com](http://www.toli.com)

